







Creating a High Performance Home

This guide provides tips to help you make your home more:



- Affordable to operate
- Healthy
- Easy on the environment
- Valuable
- Durable

The "Three Big Bang" Techniques of a High Performance Home:



Energy-Efficient Homes	4
------------------------	---

Water Heating 5

Electric Lighting	7
Daylighting	10
High Performance AC	13
Appliances	15

Comfortable Homes

Cool Roofs	18
Cool Windows	21
Cool Walls	23
Natural Ventilation	24
Ceiling Fans	26
Site Planning/Landscaping	27

17

33

Resource-Efficient Homes 28

Building Materials	. 2	8
Water Conservation	. 3	0
Construction Waste Management	_ 3	1
Recycling and Composting	3	2

Healthy Homes


Indoor Air Quality	 34	
Termite Control	 35	,

In Addition


Energy-Efficient Homes Checklist	36
Comfortable Homes Checklist	37
Resource-Efficient Homes Checklist	38
Healthy Homes Checklist	39
Additional Resources back pa	ge

Energy-Efficient Homes

Typical utility bills are \$90 per month. The cost jumps up to more than \$200 per month for air conditioned homes. Savings of \$30 to \$50 per month are feasible. This pie chart shows electrical energy use for a typical family of four in Hawaii. Source: Hawaiian Electric Company, Inc.



Energy Cost Reduction Strategies



Avoid the Need for Air Conditioning

Air conditioning is expensive to install and operate. Save money and still be comfortable by following the Comfortable Homes strategies described later. The Cool Roofs recommendations are especially important. Save about \$18,000 in cost for central systems and \$400 per year in energy costs by avoiding air conditioning. Air conditioning can also be a source of mold and mildew.

Water Heating

(Big Bang Technique #1)

The best opportunity to cut your utility bill

A utility-approved solar water heater is the most important energy savings step for a Hawaii home. Conventional water heating is a big expense. It accounts for about 40% of the utility bill in a Hawaii house. A solar system isn't cheap, but much of the installation cost can be offset by state tax credits and utility rebates, and may help you qualify for an Energy Star® Mortgage.*

Types of water heaters



BEST Solar

Saves 80% - 90% of water heating costs. Energy savings can pay back the installation cost in less than 4 years.

BETTER

Heat pump

Works like an air conditioner in reverse, heating water and cooling air. Look for a coefficient of performance (COP) of 2.7 or better.

FAIR

Gas

Some savings, requires gas service. Consider a high efficiency model with an energy factor (EF) of 0.65 or higher.

POOR

Electric Resistance

Most common but most expensive to use. Check the Energy Guide label and buy the most energy efficient water heater.

Costs


	Type of water heater	Installed cost (for average size system)	Energy cost per year (for average family of four)	
BEST	Solar	\$2,000+	\$55	
BETTER	Heat Pump	\$1,000+	\$220	
FAIR	Gas	\$400	\$370	
POOR	Electric Resistance	\$350	\$520	


*Does your new home qualify for an Energy Star[®] Mortgage? A utility-approved solar water heater is all that is needed for a non-air conditioned Hawaii home! Call the utilities listed on the back page for more information.

4

Water Heating

(Big Bang Technique #1)





Típs & Techníques

■ Get a State of Hawaii tax credit for solar and heat pump water heating systems. In 2002, the savings are 35% for solar systems.*

Electric

\$520

- Call your utility company when planning your solar system. Utility incentives may be available for efficient water heating systems, further reducing the cost. Utilities may also provide lists of qualified contractors.
- Insulate hot water pipes with at least ½" foam or 1" fiberglass insulation.
- Set the thermostat for 120°F or less.
- Plan for solar water heating in the future (if not possible at present) by providing hot water pipe stubs.
- Install water-conserving fixtures like low-flow showerheads and aerators in faucets.
- Consider horizontal-axis (front-loading) washing machines that use much less water.

Cost _____

A typical solar system costs about \$4,000, but the cost to the homeowner can be much less due to tax credits and utility incentives.*

Savings _____

Savings range from \$400 to \$600 per year compared to an electric water heater (based on 14.5¢/kWh).

*See the Additional Resources section on the back of this brochure for places to find latest information on tax credits, utility rebates, Energy Star® Mortgages, and other incentives.

Lighting

A cost effective investment


An efficient lighting system uses fluorescent lamps as the primary light source and may selectively use incandescent (also halogen, a type of incandescent) for accent lighting and for applications where the light is usually off (like exterior lights on motion sensor controls).

Modern fluorescent lighting can provide excellent color rendering and be free of flicker and hum. And start up is nearly instantaneous with electronic instant-start and rapidstart ballasts. Fluorescent lighting costs more initially but pays for itself. Remember that fluorescent lamps last 10 to 20 times longer than incandescents, saving energy all the while, so the lifetime cost is much lower. Plus, fluorescent lights do not emit as much heat as incandescents.

Explaining lighting terms

Color Appearance

Correlated Color Temperature (CCT) refers to the apparent color of a light source. Warmer colors have lower CCT, cooler colors have higher CCT. Fluorescent lamps cover a wide range. The best choice is a matter of personal preference.



Color Rendering

Color Rendering Index (CRI) tells how well a light source shows colors. A higher value (up to 100) generally means more accurate colors. For fluorescent lamps, choose a CRI of 70 or higher for most uses and consider a CRI of 80 or more for applications like bathroom vanity lights.

Lumens & Efficacy


Lumens describe a quantity of light. Efficacy is expressed in lumens per watt; bulbs that use fewer watts to produce the same amount of light have higher efficacy.

()) 4-ft. T-8 Flourescent	Compact Flourescent Lamp (CFL)	Standard Incandescent
32 watts	13 watts	60 watts
3,000 lumens	800 lumens	800 lumens
90 lumens per watt	55 lumens per watt	13 lumens per watt
BEST	BETTER	POOR

Ballasts

Ballasts are devices that control both the voltage needed to start a fluorescent bulb and the current required during bulb operation. Electronic ballasts are more efficient than magnetic ballasts, run cooler, and eliminate flicker and humming. Electronic ballasts may not be available for small fluorescent lamps like 9 or 13 watt CFLs.

Efficient Electric Lighting



Efficient Electric Lighting

Típs & Techníques _____

What to Look for in Fluorescent Lights:

- CRI of 80 or greater for good color rendering.
- Electronic ballast for energy savings.
- CCT of 3,000K or less for a warm look, 3,500K for neutral color, and 4,100K or higher for cool appearance. To match the yellowish color of typical incandescent lamps, many CFLs have a CCT of 2,700K.
- For long tubes choose T-8 (1" diameter) bulbs with electronic ballasts instead of T-12 (1.5" diameter).

Other tips:

- Conserve energy with controls like timers, occupancy sensors, and photo sensors.
- Use halogen lamps sparingly for accent lighting. They are not very efficient and can even be dangerously hot in some fixtures like torchieres. A CFL torchiere may save enough energy in its first year of use to pay back the entire extra cost of the better technology.
- A few CFLs can use typical residential dimmers, but read each CFL package carefully! Most CFLs CANNOT operate properly with dimmers, and could cause a fire.
- Most other types of fluorescent lamps can also dim, but the proper ballasts and controllers are expensive. If you buy a dimming ballast, use the controls and lamps the ballast manufacturer recommends.
- White colored ceilings and walls increase light levels.


Daylighting

The other solar energy system

Sunlight connects us to the outdoors and natural rhythms. It can reduce electricity bills, too. The trick to using daylight in Hawaii is to get enough light without too much heat.

Daylight and windows


Windows are usually a home's main source of daylight. Try to block direct sunlight and bounce light onto the ceiling.



Daylighting

Skylights


Skylights can provide very pleasant light, making a room feel bright and airy. Follow these tips to get good light distribution without creating excessive heat and glare.



Skylight size	Floor area covered (square feet)
1.5' x 1.5' (2.2 sq. ft.)	50 - 110
2' x 2' (4 sq. ft.)	100 - 200
2' x 3' (6 sq. ft.)	150 - 300
2' x 4' (8 sq. ft.)	200 - 400

Daylighting

Tubular skylights are often less expensive to install and can help brighten spaces that might otherwise be difficult to daylight.



Tips & Techniques_

- Light-colored interior finishes are critical for good light distribution. A white ceiling is recommended.
- Minimize area of east- or west-facing windows or use polywood shutters.
- Blue or green glass transmits more visible light than gray or bronze tints (see Cool Windows section).
- Rooms with higher ceilings and narrow floor plans are easier to daylight.
- Consider several smaller skylights instead of one larger skylight for better light distribution.
- Cost .
 - \$100 \$200 plus installation
- Savings _
 - Save up to \$50 per year in lighting electricity cost for each skylight.

High Performance
Air-Conditioning

Bígger ís not always better

In terms of energy, economy, and health, it is best **NOT** to air condition your home. However, if you live in a dusty or noisy area, you might want AC. In that case:

- Follow the recommendations for Cool Roofs, Walls, and Windows (to minimize your AC use).
- Compare Energy Guide labels.
- Seal air leaks in the home and ducts.
- Choose an AC unit that is not too big, but just the right size.

Not Too Big!

Smaller AC units run more efficiently and usually provide better comfort and air quality. They don't cycle on and off as much, and they remove more moisture from the air, reducing the risk of mold and mildew growth.

How much AC do I need?		
Floor area (in square feet)	Capacity (Btu/hr.)	
150 - 250	5,000	
200 - 300	6,000	
250 - 350	7,000	
300 - 400	8,000	
350 - 450	9,000	
400 - 550	10,000	
500 - 650	12,000	
575 - 800	14,000	
750 - 1000	18,000	

Applies to window or ductless spilt system AC. Consult contractor for central AC size.

Window Air Conditioner

Performs most efficiently in a shaded location, like on the north side of a home.

Look for EER* of 10 or higher.

Install on a level surface

Ductless Split System AC

Consider units with multi-speed fans & compressors for better overall performance.

Look for SEER**

of 11 or better.



HAWAII HOMEOWNER'S GUIDE TO ENERGY, COMFORT & VALUE

High Performance AC

Central AC System

Install a radiant barrier or insulation under the roof to help keep ducts cool.

Try to place outdoor unit in a cool shaded spot. Choose a system with SEER of 13 or higher. Mechanically fasten (with screws or nylon straps) and seal all connections with mastic or aluminum tape with butyl adhesive. (NOT cloth duct tape).

Insulate ducts to at least R-4.

A multi-speed fan and compressor provide better comfort and efficiency.

Provide return vents or transfer grilles for each room with a supply vent.

If using a pre-insulated flexible duct, stretch it to its full length, and don't allow sharp turns. Otherwise airflow drops dramatically.

Típs & Techniques

- Before installing AC check the recommendations for Cool Roofs, Walls, Windows, and Natural Ventilation. Do not air condition your home unless absolutely necessary.
- Seal joints in walls, floors and ceilings. Use acrylic latex, polyurethane, or silicone-based sealants.
- Choose high-quality, low air leakage windows and doors or seal them with weatherstripping.
- Provide a drain for condensed water from the cooling coil. Always empty the drain pan to prevent mold growth.
- Make sure that AC systems are easily accessible for maintenance.
- Hire a contractor to periodically clean coils and check refrigerant charge.
- Cost.
 - Electricity cost for a window AC is \$0.20 to \$0.40 per hour and can add up quickly. A typical central AC costs in the range of \$0.60 to \$1.00 per hour. Annual AC costs are \$300 to \$500.
- Savings -

14


Proper sizing and installation saves 20% to 30% or more on AC costs.

Energy-Efficient Appliances

The savings add up!

Over the life of most household appliances, their operation costs will far exceed the original purchase price. Energy-efficient appliances may initially cost more than standard appliances, but cost much less to operate.

Average monthly energy costs for common household appliances (based on utility rate of 14.5¢ per kilowatt hour of electricity):



Look for energy efficiency labels on new appliances

Read the Energy Guide labels to compare energy costs. Appliances with the ENERGY STAR and Green Seal labels are efficient choices.



Energy-Efficient Appliances

Refrigerators

- Compare Energy Guide labels for savings.
- Buy the right size 14 to 17 cubic feet for
 3 to 4 occupants.
- Choose a model with top or bottom freezer rather
 than side-by-side.
- Avoid models with ice makers and through-door water dispensers.
- Look for separate controls for the freezer and refrigerator compartments.
- ✓ Provide 3" of air space around coils for them to operate efficiently.
- Place refrigerator away from heat sources such as stoves, ranges, and dishwashers.
- ✓ Set temperatures at about 36°-38°F in the refrigerator and 0°-5°F in the freezer.

Laundry Equipment

- Use a clothes line to replace electric or gas clothes dryers.
- ✓ Use a horizontal-axis, front loading washing machine to save water and water heating energy.
- ✓ If you must use a dryer, select one with moisture sensors and cooldown cycles.
- Clean dryer filter often, vent clothes dryer directly to the outside of the home.

Cooking Appliances

- Consider induction or halogen cooktops instead of electric burners.
- \checkmark Install a range hood to vent heat and humidity.
- Use microwave and toaster ovens rather than a full-size electric oven.
- ✓ Install self-cleaning ovens; they have better insulation.
- Use a convection oven instead of a standard electric oven.
- ✓ Select ovens with windows so that you don't need to open the oven to look at what's cooking.

Dishwashers

16

- Install dishwashers with built-in booster heater so you can lower the water heater temperature setpoint.
- Select a unit with an energy-saving wash cycle.
- ✓ Use the air-drying cycle to save energy.
- Regularly clean the filter at the bottom of the dishwasher.

Comfortable Homes


There's more than one way to keep cool

A comfortable Hawaii home uses a combination of strategies to keep cool. In most cases, air conditioning is unnecessary with proper attention to comfort design.

The keys to Hawaiian comfort:


Air Temperature

Keep the sun's heat out and stay cooler.



Cool Roof (page 18)

Cool Window (page 21) (let the view in and keep the sun out)



Air Movement

A gentle breeze increases the rate of evaporation from your skin and helps you feel much cooler.



- Natural Ventilation (page 24)
- Ceiling Fans (page 26)
 - Site Planning (page 27)

Radiant Temperature

Cooler indoor surfaces help you feel comfortable.






(Big Bang Technique #2)

To cool your home, start at the top

A cool roof is essential for a comfortable home. A roof's second most important job in Hawaii, after keeping out the rain, is to keep out the sun. A roof that blocks the sun's heat keeps the home cooler and much more comfortable. If your home has air-conditioning, a cool roof will eliminate or reduce its use, cutting your electricity bills. Eliminating air conditioning will save up to \$18,000 for the cost of a new system and about \$400 a year in electricity.

Típs & Techníques ____

- Ventilate the attic, especially when using a radiant barrier. A baffled ridge vent and large soffit vents are recommended (see page 20).
- If a ridge vent is not feasible, use a solar powered vent fan in combination with eave or soffit vents.
- Avoid compressing insulation as that will reduce its effectiveness. Keep attic vents clear if installing insulation.
- Consider encapsulated products if choosing fiberglass insulation to reduce the chance of contact with fibers.
- As an alternative to fiberglass, consider blown-in insulation made from recycled paper and treated with fire and pest retardant.
- Install a white roof to keep the roof surface 20° - 40°F cooler.




\$360 - \$450 per year in reduced air conditioning costs for an average-sized house. ■ Cool Roofs

(Big Bang Technique #2)

How insulation keeps you cool:

By blocking heat on the roof from getting into the attic, the ceiling and the rest of the house stay cool and comfortable.



Cool roof options:

R-19 Fiberglass Insulation

Insulation is measured by "R-value." The higher the R-value, the thicker and more effective the insulation. For Hawaii, an R-value of R-19 (about 6" thick) is recommended.

Good to ______

...or better here (between the ceiling joists)


Foam Board Insulation

Foam board insulation works well for open beam ceilings. A thickness of 2" is recommended. May need wood sheet on top of foam board on which to nail roof shingles. Foam board insulation (2" thick) Exposed wood ceiling

Radiant Barrier

Radiant barriers are measured by their "emissivity" or ability to keep heat from radiating down to the ceiling. A radiant barrier with an emissivity

rate of 0.05 or less is recommended.



*Provide a minimum 3/4" air gap next to the shiny face. An air gap on both sides is preferred, if possible.


Cool Roofs

(Big Bang Technique #2) Attic Ventilation

For homes with attics, good ventilation is recommended when a radiant barrier is installed. And ventilation is also helpful even when the attic floor is insulated.

Ridge and Eave or Soffit Vents

Combine a baffled ridge vent with eave or soffit vents for best airflow.



front view


side view

Soffit Vent

attic


attic

Eave vent lets fresh



Total vent area should be at least 1/2 square inch for each 1 square foot of attic area. Divide area equally between ridge and eave vents.

Other Venting Options



Cool Windows

Keep cool with a view, too

Windows deserve attention because they are the easiest way for the sun's heat to enter into your house. The best cooling strategy is shading. Overhangs, awnings, and trees keep the sun from striking the window. Where exterior shading isn't feasible, invest in solar-control windows.

Solar Control Windows					
Typical values (see below for details)					
		HGC*	VLT **	UV% *	** Cost
11	Low-e ²				
BEST	windows	.36	.70	43%	+\$4.00/s.f.
, Br		Make sure to get the "tropical," "sunbelt," or "low-e squared" type of low-e window with a SHGC of less than 0.40.			
Doubl	e-paned				
	Green/				
BETTER	blue	.69	.83	42%	+.50¢/s.f.
BE	tinted				,
	Gray or				
GOOD	bronze	.69	.61	35%	+.50¢/s.f.
Ge	tinted				
POOR	Clear	.86	.90	71%	_
VC.					
Look for the SHGC on the window's NFRC label.					
*SHGC = Sol	ar Heat Ga	ain Coef	ficient me	asures	the fraction
of solar heat admitted through a window; the lower the SHGC, the less heat transmitted. **VLT = Visible Light Transmission indicates the fraction of					
			e fraction of		
-	-				; the higher
the	VLT, the m	nore ligh	t that pas	ses thre	ough.
***UV = Ulti	raviolet ligh	nt. Lowe	ring the L	JV light	coming in

Window Film

For existing windows, plastic window films can be applied to reduce heat. A wide variety are available. Applied to clear glass, they reduce SHGC from around 0.9 down to as low as 0.3.

people, furnishings, carpeting, and drapes.

through a window can help prevent sun damage to

High performance films reduce heat while allowing in visible light. Look for a SHGC of 0.40 or less, together with a VLT of no less than 0.40.



Cool Windows

Orientation & Window Blinds

Try to orient your biggest windows facing north or south so they can be more easily shaded with a roof overhang.

Use vertical shades for east- & west-facing windows. Use horizontal shades for

north- & south-facing windows

True north

Compass north


NOTE: Be aware that compass north is not equal to true north. In Hawaii, true north is 10° east of magnetic north. So try to face the widest part of your house 10° east of magnetic north.


south

Roof Overhangs

To determine how much of a roof overhang to build:

Use a 45^o angle for overhangs over windows that face south (sun is lower in the sky in the south).





Típs & Techníques

- Windows on the north or south side are preferred because they are easiest to shade.
- Avoid west-facing windows unless you really like the view, because it is difficult to block the afternoon sun.
- East-facing window area should be minimized as well, especially in hot parts of the islands.
- Vinyl or wood frames block heat gain somewhat better than aluminum frames.
- White frames are a little better because they reflect sunlight and stay cooler.

Cost _____

\$0.30 - \$4.00 per square foot (depending on strategies)

Savings -

Up to about \$200 per year for a typical home with air conditioning.


Cool Walls

Keep the sun out and stay cool

Unshaded walls can get very hot and make your home uncomfortable. The best "cool wall" strategy is shading with overhanging eaves, lanais, or landscaping. If complete shade isn't feasible, use insulation or radiant barriers in the exposed walls as illustrated below. In air conditioned homes, all walls should have insulation or radiant barriers to reduce electricity bills and air conditioner size requirements.

Cool wall options:

Insulation and radiant barriers work well to keep the sun's heat from seeping through the walls into your home.




Natural Ventilation

(Big Bang Technique #3)


Cooling with nature

Gentle trade winds can make air conditioning unnecessary in most areas of Hawaii. Fortunately, summer is the windiest time of year in Hawaii, and you can capture cooling breezes to keep your home comfortable. Natural ventilation also helps reduce health hazards such as mold and mildew.



Where should I put the openings?

Orientation about 45° to wind direction is best.




Natural Ventilation

(Big Bang Technique #3)

How big should the openings be?


A reasonable rule of thumb is that the opening area should be about 12% of the floor area. Use more area for calm locations and less for very windy locations. Remember that the opening area is less than the total window area.

Opening Area as Percentage of Window Area:



The "Chimney" Ventilation Alternative

Take advantage of the bouyancy of warm air to ventilate the house, even when no one is home.



- Draw air from a cool shaded spot, as low as possible.
- Place outlet vents as high as possible, options include: vented skylight, ridge vents, vented cupola(s), gable vents and exhaust fans.
- Provide generous vent area:

at least 1 square inch per 1 square foot of floor area for combined inlet and outlet area, roughly 50/50 inlet/outlet.

Consult an architect with stack ventilation experience for design details.

Natural Ventilation

(Big Bang Technique #3)


Ceiling Fans

Ceiling fans create a gentle breeze that can take over comfort duties when the wind quits. They are also an excellent choice in noisy

375_____ 52" (


or dusty areas where it's unpleasant to keep the windows open.

Multi-speed fans can be adjusted to individual preferences.



*To calculate the square footage of a room, multiply the width times the length. For example, a 10'x10' room would be 100 square feet.

400+_____ 2 Fans Needed _____




Site Planning/Landscaping

Plan to stay cool


Through careful planning, you can stay cooler by keeping the air surrounding your house cooler, too.

Site Planning & Landscaping for Comfort

Orientation is important. Try to minimize the area of east- and west-facing walls and windows because they are difficult to shade from the sun.



See the Cool Windows recommendations (pages 21 & 22) for shading south- and north- facing windows.



1. Build trellises to shade the house and paved areas.

2. Use light-colored roof to stay much cooler and help keep the surroundings cooler, too.

3. Use new or existing trees to shade walls and grounds.

4. Use light-colored exterior surfaces, such as creamcolored concrete, that stay cooler in the sun.

5. Limit area of unplanted and paved surfaces.

6. Use porous paving materials that can handle some auto and foot traffic but still allow grass to grow in gaps.

See the Natural Ventilation section (pages 24-26) for more site planning considerations.

Resource-Efficient Homes

Resource-efficient homes make the best use of natural, human, and built resources. Worldwide, buildings are responsible for 12% of freshwater withdrawals, 25% of wood harvest, and 40% of material and energy flow.

In recent years innovation has made available a variety of resource-efficient products that minimize the overall environmental impact of a home by conserving the raw materials and natural resources used to build it. Conservation can occur at any point in the product's life: production, use, or disposal.

Building Materials
Reduce, reuse, recycle

Each product used to build a home represents an investment of energy, water, and raw materials, and has an impact on the environment. The environmental cost of building materials is not easily quantified, but there are several guidelines to help make good decisions.

Favor products that:

- Are produced locally.
- Foster the use of less material.
- Are durable and long-lasting.
- Include recycled content.
- Can be recycled.
- Are produced from a sustainable and renewable resource.
- Can be reused, reworked, or recycled.

Típs & Techniques_

- To minimize waste, design for standard dimensional lumber, sheathing, and panels.
- Avoid creating construction scrap.
- Specify installation with screws instead of glue to permit easy disassembly.
- Use salvaged materials.

28

Avoid unnecessary coverings or coatings.

Building Materials

Concrete

Use concrete with fly ash (a by-product at Oahu's coal fired power plant) replacing up to 30% of the Portland cement. Use epoxy-coated steel reinforcement to extend the life of concrete. Use reusable form-work to reduce waste. Use recycled concrete for fill or to make new concrete.

Insulation

Cellulose insulation is made in Hawaii from recycled newspapers or telephone books and is very resource efficient. It may be blown, poured into enclosed cavities in a dry form, or wet-sprayed. Cellulose provides fire retardancy and pest control when mixed with boric acid or sodium borate. When wetsprayed in place, it provides an excellent barrier to air leakage. Some fiberglass batt insulation is manufactured using recycled glass. Products are available with at least 30% recycled content.

Steel Framing

Steel is a durable, termite-proof, recyclable framing material. It has long-term performance and is easily recyclable. It does not contribute to poor indoor air quality. Protect studs and joists from corrosion and rust by using hot-dipped galvanizing and assembly with good quality connectors. Framing members are available with a minimum of 25% recycled content.

Lumber

Use sustainably-harvested wood that is certified by the Forest Stewardship Council (FSC). Use engineered wood products made from smaller pieces of wood. Products include glulams, oriented strand board (OSB), laminated veneer lumber (LVLs), I-joists, and finger jointed lumber. Wood preservatives such as CCA and tribucide are toxic and present environmental hazards (both during treatment and at construction waste disposal sites). ACQ and Hi-Bor are less toxic.

Roofing Materials

Roofing material should be durable, have high reflectance (see Cool Roof section), and be recyclable. Consider light-colored metal panels because they are durable and recyclable. Composite shingles, tiles, and panels made from fiberreinforced cement products use recycled-content material and are durable (but not recyclable). If using asphalt shingles, use those with high recycled content.

Floor Finishes

Consider salvaged, laminated, and veneered wood flooring. Laminated flooring makes efficient use of lumber and provides a durable surface. Bamboo flooring (plywood and tongue-andgroove) is available locally.

Natural linoleum is highly durable and made from renewable, biodegradable materials such as wood dust, linseed oil, and cork.

Traditional carpeting waste and scrap does not decompose readily and contributes significantly to the construction waste stream. If using carpets, consider using those made with Nylon 6 or Nylon 6,6 that offer a high level of recyclability, or those made with recycled content. Modular carpet tiles also reduce waste because they can be replaced selectively. Wool carpets (or other natural fibers) are biodegradable and renewable. Minimum amounts of low- or non-toxic adhesives should be used to lay the flooring.

Gypsum Board

Drywall manufactured with recycled gypsum is equivalent in quality and price to conventional drywall.

Water Conservation


Don't let it go down the drain

Xeriscaping

Design water-efficient, low-maintenance landscaping (xeriscaping) by using drought-tolerant landscaping and native plants. Irrigation costs and water usage can be lowered 30%-60% through xeriscaping. Some drought-tolerant plants that grow well in this climate are:

Trees: wiliwili, kiawe, plumeria, autograph tree.
Shrubs: naupaka, plumbago, 'ulei, native plumbago, akia, ilima, kukui, natal plum, wax fiscus.
Vines: bougainvillea, cape honeysuckle.
Groundcovers: succulents, pohinahina, prostrate ilima, purple lantana, creeping rosemary.

Xeriscaping also includes improving the soil; reducing lawn areas by planting ground cover and local grasses; using mulch; and collecting surface runoff to water the plants.



Rainwater Harvesting

Use rainwater-harvesting systems for garden applications. Also consider rainwater for showers, sinks, laundries, dishwashers, toilets, and, sparingly, even for drinking. Rainwater is collected from roof or ground level surfaces and stored in a cistern. The water is then filtered and delivered to terminals through pumps.

Gray Water

30

Use gray water systems for nonpotable purposes like drought-resistant landscape irrigation and flushing toilets. Gray water is untreated "used" water that is not contaminated by toilet waste including water from showers, bathroom washbasins, and washing machines. It does not include wastewater from dishwashers, kitchen sinks, or laundry water from soiled diapers. Construction
Waste Management

Waste not, want not

With a little planning, it's possible to reduce waste before it happens. In addition to helping preserve the Islands' environment, you can also save quite a bit in waste disposal fees.

Típs & Techníques

- Have your contractor use the "Construction and Demolition Waste Management Guide" available from DBEDT's Clean Hawaii Center. Website: www.hawaii.gov/dbedt/ert/chc.
- Begin by buying recycled material.
- Reuse as much material as possible on your construction project.
- Separate recyclable and reuseable materials from non-recyclable materials and supply them to a business, charitable organization, or hauler.
- Set up specific areas for operations such as cutting and recycling, and clearly label these areas.
- Use suppliers who use recyclable or reusable packaging.
- Use reusable form-work for concrete.
- Provide weather protection for stored materials.
- Avoid the need to truck dirt on or off the site by balancing site cut and fill.
- Preserve existing vegetation and reuse as landscaping.
- Reuse material from deconstructed and demolished buildings.
- Avoid use of hazardous materials that require special waste handling.



Buying recycled products and separating recyclable materials from your garbage makes a big difference. Consider creating a space in your home to collect recyclable materials. Check with a local recycling center to



see what they can take and what needs to be

separated. Then set up bins to hold recyclables like newspaper, cardboard, mixed paper, glass, steel, plastics, and aluminum.

To find listings of products made from recycled materials, check out the Clean Hawaii Center at www.hawaii.gov/dbedt/ert/chc. You may also contact county recycling programs and drop-off centers. See back cover for their phone numbers.

Compositing

Composting can help lighten the load in your garbage can each week. If you cannot compost, contact the county for green waste pickup.

What is it good for?

Compost can be used as a soil supplement in flower beds, vegetable gardens, lawns, and tree planting. It helps to conserve moisture, prevent erosion, and reduce weed growth. It also helps control diseases and pest infestation in plants, reduces the use of chemical fertilizers, and helps conserve natural resources.

How to Compost

Composting is the controlled breakdown of biodegradable yard and kitchen wastes. There are several ways to get this to happen, and fortunately nature does most of the work. Success in composting depends upon sufficient moisture and oxygen.

CAN IT BE USED FOR C	COMPOST?
YES 🙂	NO 🚡
Yard wastes like leaves, grass clippings, tree and shrub trimmings, wood chips, sawdust, and garden trimmings.	Meat, bones, fats, grease, oils, dairy products, and raw manure. These materials easily attract animals and emit odors.
Kitchen wastes like coffee grounds, tea bags, raw vegetable scraps, fruit skins/cores/rinds, and corn husks	(Refer to county recycling and composting programs.)

Healthy Homes

Most Americans spend about 60% of their time at home, so a healthy home environment is important. And good indoor air quality is probably the number one feature of a healthy home.

Keep Dry and Clean (Prevent Mold)

Mold prevention is our top indoor air quality priority. Molds (also called mildew) are fungi. Some mold spores can produce an allergic reaction and a few are very toxic.

Typical Symptoms Include:

- Wheezing, difficulty breathing, and shortness of breath.
- Nasal and sinus congestion.
- Eye irritation (burning, watery, or reddened eyes; nose or throat irritation; skin rashes or irritation).
- Dry, hacking cough.

It's tough to completely eliminate mold growth, but there are ways to help prevent it. The important thing to know is that mold needs both moisture and food, so the basic strategy is to keep things dry and clean.

Mold Prevention Design Strategies:

- Use overhangs to protect walls from rain.
- Avoid air conditioning; however, if you must use AC, carefully insulate AC ducts and provide a well-sealed vapor barrier (typically plastic) around the insulation.
- Avoid the use of vinyl wall covering because it can seal moisture inside the wall.
- Minimize surfaces (drywall, carpet, grout, and rough unfinished wood) that collect dust or dirt. Whenever moisture is likely, use smooth surfaces (tile, finished hardwood, or sealed concrete) that are easy to clean.

Maintenance Strategies:

- General cleanliness contributes to a mold-free environment.
- Immediately dry out materials that get wet from spills or plumbing leaks. Mold can start growing within 24 hours.
- Many materials cannot be properly cleaned once contaminated and may need to be thrown out. For guidance on cleanup see the U.S. Environmental Protection Agency web site: www.epa.gov/iaq.

HAWAII HOMEOWNER'S GUIDE TO ENERGY, COMFORT & VALUE

32

husks.

Indoor Air Quality

Provide Fresh Air

A good common-sense method to help maintain good indoor air quality is to provide natural ventilation. Design tips for natural ventilation are covered on pages 24-26. Of course, this strategy is less useful in areas that are very dusty or have heavy outdoor contamination.

Choose Healthier Materials

The materials we choose to build and furnish our homes have an impact on indoor air quality. Whenever possible choose materials with little or no off-gassing of volatile organic compounds (VOC), which can include irritants, toxic gases, or noxious odors.

Wood Products

- Avoid products with particleboard, which typically contains formaldehyde.
- Use formaldehyde-free or exterior glue plywood instead of particleboard for countertop bases.
- Use exterior grade plywood, wood, or formaldehyde-free medium density fiberboard (MDF) for structural sheathing.
 Avoid wood treated with toxic compounds such as CCA and ACZA. ACQ and Hi-Bor are considered less toxic.

Finishes

- Minimize use of carpet and upholstered materials because they can off-gas formaldehyde, permit accumulation of airborne contaminants, and foster growth of mold and dust mites.
- Maximize use of hardwood floors (factory-finished with low VOC finish or field finished with water-based finish) and concrete or tile.
- Use latex and water-dispersed acrylic paints and sealers with low or zero VOC content.
- Paints should be formaldehyde-free and ammonia-free (check ingredients). Do not be misled by "low-odor" advertising (low-odor products may still have troublesome ingredients).
- If adhesives are necessary, use low VOC, water-based products.
- Be aware that vinyl, used in flooring and wall covering, gives off toxic gases when burned.

Keep Clean During Construction

- Install insulation with care to ensure that occupants are not exposed to irritants such as fibers, retardants, stabilizers, and chemicals.
- Thoroughly clean the building before installation of carpet and baseboard trim.
- Perform final clean-up after construction with a high efficiency particulate air (HEPA) filter vacuum.

Termite Control

Destructive Insects

Termites are a serious threat to the health of buildings in Hawaii, and conventional termite control strategies can present health risks to occupants and damage to ground water. Environmentally benign wood and ground treatment, combined with preventive design and

maintenance for termite control, will enhance the health of the home and its occupants. Termites also create a health challenge for Hawaii homeowners because pest control methods may use toxic chemicals.

Preventative Design and Maintenance

- Design with materials that are impervious or unattractive to termites such as concrete, steel, and plastic.
- Poured concrete walls are more termite-resistant than concrete blocks.
- Use alternative, environmentally friendly control methods such as stainless steel mesh and basaltic termite barriers.
- Provide easy access for termite inspection during occupancy.

Ground Treatment

- Several effective and less-toxic chemicals are now available for soil treatment.
- For effective soil treatment provide at least 24-hours for the chemicals to dry and protect the treated soil layer with a slab, gravel, or surface soil layer.
- Termite bait systems are good insect growth regulators.
- Keep drainage flow routed away from the building by using appropriate grading and site drainage systems.
- Keep plantings at least 24" from the building perimeter.
- Keep the site and work area clean and clear of any organic debris, wood scraps, cardboard, and paper.
- When clearing vegetation, thoroughly remove all roots.

Wood Treatment

- When treating wood, consider safer alternatives such as borate wood treatment (where it is unlikely that the wood will get wet), ACQ-treated wood, and naturally termiteresistant wood.
- When using oil-borne solvents, allow for adequate drying time before installation.

Energy Efficient Homes

36

r to section pages for more details		Refer to section pages for more details	
Nater Heating Big Bang Technique #1)	page 5	COOL ROOFS (Big Bang Technique #2)	page 1
Install utility-approved solar water hea	ating.	Install R-19 fiberglass insulation, 2" board insulation and/or a radiant bar	
Check for availability of state tax cred rebates and Energy Star® Mortgages		Ventilate your attic with ridge and ea	ve vents
Set your water heater's thermostat to 120°F or less.		Choose a light-colored roof surface.	
Install water conserving fixtures and a	appliances.	Cool Windows	page 2
Choose a horizontal-axis, front-loading washing machine.		Shade windows using overhangs.	
		Choose solar control windows.	
Lectric Lighting page 7 Use "full-size" fluorescent lamp fixtures for best		Avoid hot morning and afternoon sun by minimizing the size of east- and west-facing windows.	
efficiency and color rendering. Choose electronic ballasts and T-8 flu	iorescent	Use window film for existing windows	s.
lamps.		Cool Walls	page :
 Replace standard incandescent light bulbs with compact fluorescent bulbs (CFLs). Replace halogen "torchiere" floor lamps with compact fluorescent floor lamps (halogen lamps get very hot and use much more energy). 		 Install R-11 insulation or a radiant barrier in walls exposed to sun. Choose light colors for wall exteriors. 	
Use light shelves and clerestory wind help bring daylight into rooms.	lows to	Orient your windows 45° to wind dire	ection.
Install properly-sized skylights.		Choose casement windows to better air flow.	· capture
Hígh Performance AC	page 13	Make opening area about 12% of the area of the room to be cooled.	ə floor
Do not use AC except under extreme Check the recommendations for Cool Walls and Windows (may not need A	Roofs,	Install a multi-speed ceiling fan.	
Buy the proper size air conditioner for your home (not too big!) - see page 13.		Site Planning/Landscaping	page 2
		Shade south-facing windows and wa roof overhangs.	lls with
Efficient Appliances page 15 Look for Energy Guide labels to compare energy costs for various appliances.		Build a trellis and use trees to help shade walls.	

UE 37

Resource Efficient Homes

Refer to section pages for more details	Refer to section pages for more details	
Building Materials page 28	Preventing Mold page 33	
Use concrete with fly ash and recycled concrete.	Keep your home clean and dry.	
Use cellulose insulation or insulation products that use at least 30% recycled content.	Use overhangs to protect walls from rain.	
Use steel framing and sustainably harvested wood for home construction.	Avoid air conditioning. If you must use it, carefully insulate AC ducts.	
Use composite shingles made from fiber-	Avoid the use of vinyl wall covering.	
reinforced cement products for roof.	Immediately dry out materials that get wet from spills or plumbing leaks.	
If you must use carpeting, choose carpet made with recycled content.	Minimize surfaces such as carpet, grout, and rough unfinished wood that collect dust or dirt.	
Water Conservation page 30	Whenever moisture is likely, use smooth surfaces such as tile, finished hardwood, or sealed concrete that are easy to clean.	
Use xeriscaping to save on water usage for landscaping.		
Harvest rainwater for garden use.	Indoor Air Quality page 34	
Use a gray water system for landscape irrigation and for flushing toilets.	Provide fresh air to help naturally ventilate your home.	
Construction Waste Management page 31	Use latex and water-dispersed acrylic paints and sealers with low or zero volatile organic compound (VOC) content.	
Have your contractor use DBEDT's	Avoid products with particleboard.	
"Construction and Demolition Waste Management Guide" before, during, and after building your house.	Use formaldehyde-free fiberboard; avoid wood treated with toxic compounds such as CCA.	
Recycle and reuse as much construction material as possible.	Termíte Control page 35	
Avoid using hazardous materials that require special waste handling.	Use naturally termite-resistant woods or materials such as concrete, steel, and plastic that are unattractive to termites.	
Recycling/Composting page 32	When using ground treatment, choose less-toxic chemicals.	
Recycle your household newspapers, glass, plastics, cardboard, and aluminum. Create an		
area for collection.	Use termite bait systems to help control termites.	
Buy recycled products. Look for the "Buy Recycled Hawaii" label.	Keep drainage flow away from home.	
Use composting to recycle yard wastes and appropriate kitchen wastes for soil supplements in your garden.	Keep plantings at least 24" from the building perimeter.	

Healthy Homes

Additional Resources

For more detailed information, see these **DBEDT** Publications:

- Comfortable Homes in Hawaii Brochure
- Hawaii Energy Tax Credits
- Homeowner's Guide to Solar Water Heating
- Ceiling Insulation for Your Home

For information about potential utility programs:

- HECO (Oahu): 947-6937, www.heco.com
- HELCO (Big Island): 969-0127
- Kauai Electric: 246-8280
- MECO (Maui, toll-free): 1-888-632-6786

For more energy efficiency information:

- U.S. Department of Energy, Energy Efficiency and Renewable Energy Network: www.eren.doe.gov
- U.S. Environmental Protection Agency,
- Energy Star program: www.energystar.gov American Council for an Energy
- Efficient Economy www.aceee.org
- Alliance to Save Energy www.ase.org

For recycling information:

- City & County of Honolulu: 692-5410
- County of Hawaii: 961-8083
- County of Kauai: 241-6891
- County of Maui: 270-7880
- Clean Hawaii Center, www.hawaii.gov/dbedt/ert/chc

The measures in this booklet will help develop a home that meets the levels in the Hawaii BuiltGreen[™] Home Program rating system. Contact the Building Industry Association of Hawaii for more information (847-4666, ext. 210; www.bia-hawaii.com).

This document has been catalogued as follows:

Hawaii. Dept. of Business, Economic Development and Tourism. Energy Resources and Technology Division.

> Hawaii homeowner's guide to energy, comfort and value. Honolulu: 2002

1. Dwellings-Energy conservation-Hawaii. TJ163.5.D86.H31.2002

This document was prepared with the support of the U.S. Department of Energy, Grant DE-FG51-97R020881 and DE-FG51-02R021337. Any opinions, findings, conclusions, or recommendations expressed herein are those of the author(s) and do not necessarily reflect the views of, nor constitute an endorsement by, the U.S. Department of Energy, the State of Hawaii, nor any agency or employee thereof.



Energy, Resources & Technology Division Hawaii State Department of Business, Economic **Development & Tourism** P. O. Box 2359 Printed on recycled Honolulu, HI 96804-2359 paper with soywww.hawaii.gov/dbedt/ert based inks

